


THE ORAC USER MANUAL









3.2 installation of flexible mouldings

















Ref	Rmin (meter)	Ref	Rmin (meter)
C200F	1,5	C307F	4,6
C201F	1,4	C308F	1,4
C211F	3,2	C321F	1,4
C212F	1,4	C322F	1,2
C213F	2,3	C331F	4,6
C214F	1,1	C332F	4,9
C215F	1,7	C333F	3,7
C216F	3,4	C334F	4,1
C217F	3,4	C353F	2,9
C218F	3,7	C354F	2,9
C219F	2,9	C355F	2,9
C220F	2,9	C356F	2,9
C230F	1,1	C360F	2,9
C240F	2,3	C400F	3,2
C250F	1,1	C401F	1,8
C260F	1,5	C402F	1,8
C300F	3,4	C422F	3,7
C301F	3,0	C602F	1,4
C302F	2,1	C900F	4,0
C303F	1,8	C901F	3,7
C304F	1,7	C902F	4,0

C305F

2,9

Ref	Rmin (meter)	R"min (meter)
P1020F	0,3	08
P2020F	0,3	0,8
P3020F	0,9	1,8
P4020F	0,9	0,9
P5010F	0,5	2,7
P5020F	0,5	2,7
P5021F	0,3	0,8
P5050F	0,5	4,6
P5051F	0,5	4,6
P6020F	0,5	1,5
P7010F	0,3	3,0
P7020F	0,3	2,9
P7030F	0,3	1,5
P7040F	0,5	1,8
P7050F	0,5	1,5

Ref	Rmin (meter)	R"min (meter)
P7060F	1,5	1,8
P7070F	0,5	2,7
P7080F	0,5	/
P8020F	0,5	1,4
P8030F	0,3	0,6
P8040F	0,3	2,9
P8050F	0,3	2,7
P8060F	0,3	3,0
P9010F	0,5	2,6
P9020F	0,5	2,7
P9040F	0,5	0,9
P9050F	0,3	0,8
SX105F	0,5	/
SX118F	0,5	

ORACAXXENT®